

## **NextBASIC new commands and features (Updated 30 Mar 2020)**

This document describes new commands and features for NextBASIC (except file-related commands and editor features, described in separate documents) as at NextZXOS v2.06.

This should be read in conjunction with the other documents:

- NextBASIC file-related commands and features
- NextZXOS Editor features
- NextZXOS and esxDOS APIs
- NextZXOS Unimplemented features

A list of updates made to this document is now provided at the end.

### **New keyword tokens**

The following keyword tokens are defined in addition to SPECTRUM, PLAY and all the 48K BASIC tokens:

PEEK\$	\$87
REG	\$88
DPOKE	\$89
DPEEK	\$8a
MOD	\$8b
<<	\$8c
>>	\$8d
UNTIL	\$8e
ERROR	\$8f
ON	\$90
DEFPROC	\$91
ENDPROC	\$92
PROC	\$93
LOCAL	\$94
DRIVER	\$95
WHILE	\$96
REPEAT	\$97
ELSE	\$98
REMOUNT	\$99
BANK	\$9a
TILE	\$9b
LAYER	\$9c
PALETTE	\$9d
SPRITE	\$9e
PWD	\$9f
CD	\$a0
MKDIR	\$a1
RMDIR	\$a2

### **New errors**

Invalid mode  
Direct command error  
Loop error  
No DEFPROC  
Fragmented - use .DEFRAG

### Memory bank access

The *Next* comes with between 1MB and 2MB of RAM, divided into 16K banks. These are numbered as follows under *NextZXOS*:

- 0..7            Same as the standard RAM banks on all 128K Spectrums.
- 8..47          Additional RAM banks available on 1MB Nexts.
- 48..111       Further additional RAM banks available on 2MB Nexts.

(the remaining 256K is used for ROMs and the DivMMC interface, and is unavailable to users).

Under *NextZXOS* the memory capacity is shown in the on-screen menus. It can also be queried programmatically by examining the new system variable, *MAXBNK*, which contains the number of the highest usable bank in the system (normally 47 or 111).

*NextZXOS* uses the first 9 RAM banks as follows:

- 0            Standard 48K Spectrum memory (at 49152-65535)
- 1            RAMdisk
- 2            Standard 48K Spectrum memory (at 32768-49151)
- 3            RAMdisk
- 4            RAMdisk
- 5            Standard 48K Spectrum memory (at 16384-32767)
- 6            RAMdisk
- 7            Used for workspace and data structures by *NextZXOS*
- 8            Used for additional screen data (in lo-res, Timex hi-res and Timex hi-colour modes) and other data by *NextZXOS*

Banks 9+ are always available to the programmer, and can be accessed using the new **BANK** command (and extended **LOAD/SAVE/VERIFY..BANK..** commands seen previously).

Banks 5,2,0 (the standard 48K Spectrum memory) may also be used without restriction in the **BANK** command, but it should be noted that it is generally only safe to use the screen area (0-6911 in bank 5) plus any memory located above *RAMTOP* - the rest of the memory is managed by *NextBASIC* and should not be modified.

Banks 1,3,4,6 can be used if the **BANK 1346 USR** command has been executed.

Banks 7 and 8 are for system use only, and can never be used in a **BANK** command.

The following new commands are available to manipulate memory and banks:

#### **BANK NEW var**

Reserves the next available free bank number and assigns it to the numeric variable *var*, ready for use in other **BANK** commands. This command is useful for allocating banks for use in BASIC, allowing for cases where a resident machine code program has previously allocated banks for its own use. (It is not essential to use this command, as commands such as **BANK..LOAD** will automatically allocate the specified bank for use by BASIC, but only if the specified bank is not already in use by a resident machine code program.)

#### **BANK n CLEAR**

Marks bank *n* as free for use by other parts of the system (eg dot commands). Banks are marked as used by BASIC by commands that access them (eg **BANK..PEEK/POKE/COPY/ERASE/USR/LAYER, LAYER BANK** and **LOAD..BANK**). Marked banks remain reserved after a **NEW** command, and are only released at a reset (or with this command).

Note that the layer 2 banks (by default 9,10,11 but may be changed using the **LAYER BANK** command) cannot be released. However, if you are not using layer 2, they can be used for other purposes (including by machine code programs).

#### **BANK 1346 USR**

Allow banks 1,3,4,6 to be used in the **BANK** command. This will delete all files on the RAMdisk and unmap it from any drive it is currently mapped to (usually

M:).

#### **BANK 1346 FORMAT**

Release banks 1,3,4,6 for use by the RAMdisk again. (The RAMdisk will need to be mapped back to a drive using the **MOVE..IN** command).

#### **BANK *n* COPY TO *n2***

Copy all 16K from bank *n* to bank *n2*

#### **BANK *n* COPY *offset, len* TO *n2, offset2***

Copy *len* bytes starting at offset *offset* in bank *n* to offset *offset2* in bank *n2*

#### **BANK *n* ERASE**

##### **BANK *n* ERASE *value***

Fill all 16K of bank *n* with *value* (zero is used if *value* not specified)

##### **BANK *n* ERASE *offset, len***

##### **BANK *n* ERASE *offset, len, value***

Fill *len* bytes at offset *offset* in bank *n* with *value* (zero is used if *value* not specified)

#### **BANK *n* LAYER *x,y,w,h* TO [*rop*] *offset***

Copies data from the screen (in the current mode) to *offset* in bank *n*.

#### **BANK *n* LAYER *offset* TO [*rop*] *x,y,w,h***

Copies data to the screen (in the current mode) from *offset* in bank *n*.

[*rop*] is an optional symbol modifier which affects how the data is copied:

<b>TO</b>	(no symbol) straightforward copy
<b>TO &amp;</b>	AND the copied data into the destination
<b>TO  </b>	OR the copied data into the destination
<b>TO ^</b>	XOR the copied data into the destination
<b>TO ~</b>	copy data into the destination unless it is equal to the global transparency colour (default <b>227</b> ); in this case, leave the destination unchanged

The area of screen copied by **BANK...LAYER** is defined by the top left character position *x,y* and width *w* characters, height *h* characters. (As with windows, character positions range from *x*=0..31 and *y*=0..23 for all modes except lo-res, where they range from *x*=0..15 and *y*=0..11).

Data copied from the screen is laid out as follows, depending upon currently selected layer/mode:

#### Standard resolution (layer 0 or layer 1,1)

The attribute data comes first, stored as *h* consecutive rows of attributes, *w* bytes wide.

Following this is the screen data, stored as *h*\*8 consecutive rows of pixel data, *w* bytes wide.

The total memory used is therefore *w*\**h*\*9 bytes.

#### Timex hi-res (layer 1,2)

In this mode, each "character" position is 16 pixels wide, comprising a "left" and "right" half.

The screen data is stored as *h*\*8 consecutive pixel rows of data.

For each row, the first *w* bytes comprise the left halves of all characters.

The next *w* bytes in the row comprise the right halves of all the characters.

The total memory used is therefore *w*\**h*\*16 bytes.

#### Timex hi-colour (layer 1,3)

The screen data is stored as *h*\*8 consecutive pixel rows of data.

For each row, the first *w* bytes comprise the pixel data.

The next *w* bytes in the row comprise the attribute data.

The total memory used is therefore *w*\**h*\*16 bytes.

#### Lo-res (layer 1,0) and layer 2

The data is stored as *h*\*8 consecutive pixel rows of data.

For each row, there are  $w*8$  bytes, with each byte representing a single pixel. The total memory used is therefore  $w*h*64$  bytes.

**BANK *n* POKE *offset*,*valuelist*...**

POKEs a sequence of comma-separated values starting at offset *offset* (0-16383) in bank *n*. Each value in the list may be:

<i>value</i>	(numeric expr)	single byte
<i>value~</i>	(numeric expr)	16-bit word (low byte stored first)
<i>v\$</i>	(string expr)	string (each character stored in turn)
<i>v\$~</i>	(string expr)	string (bit 7 will be set on final char)

**BANK *n* DPOKE *offset*,*valuelist*...**

POKEs a sequence of comma-separated values starting at offset *offset* (0-16383) in bank *n*. The difference from **POKE** is that the default interpretation for a numeric value is a double-byte (16-bit word) rather than a single byte. Each value in the list may be:

<i>value</i>	(numeric expr)	16-bit word (low byte stored first)
<i>value~</i>	(numeric expr)	single byte
<i>v\$</i>	(string expr)	string (each character stored in turn)
<i>v\$~</i>	(string expr)	string (bit 7 will be set on final char)

**POKE *addr*,*valuelist*...**

**DPOKE *addr*,*valuelist*...**

Equivalents of **BANK..POKE** and **BANK..DPOKE** for the standard memory.

examples:

```

BANK b POKE "A null-terminated string",0,"A bit7-terminated string"~,1000~
BANK 25 DPOKE 12345,33206,12354
DPOKE 23606,32768-256
POKE USR "a",1,3,7,15,31,63,127,255

```

Some special-case commands are also available to read strings from memory (note that **PEEK\$** cannot currently be used in a general string expression, although this is planned for a future version of NextBASIC):

**LET *stringdest* = PEEK\$(*addr*,*len*)**

**LET *stringdest* = BANK *n* PEEK\$(*addr*,*len*)**

Reads memory region (or region of bank) to string

**LET *stringdest* = PEEK\$(*addr*,~)**

**LET *stringdest* = BANK *n* PEEK\$(*addr*,~)**

Reads a bit7-terminated string from memory or bank (NOTE: bit 7 will still be set on the string that is returned)

**LET *stringdest* = PEEK\$(*addr*,~*code*)**

**LET *stringdest* = BANK *n* PEEK\$(*addr*,~*code*)**

Reads a string terminated with the character value *code* from memory or bank (NOTE: the string that is returned excludes the terminating character)

### **Palette manipulation**

The *Next* provides 6 palettes: 2 palettes each (numbered 0 and 1) for sprites, ULA modes, and layer2. All can be manipulated in BASIC. Note that the Editor will use ULA palette 1 so it is safe to muck around with palette 0 without risk of being unable to see what's going on (the current palette will be restored by the Editor when BASIC is running).

The following new palette manipulation commands are available:

#### **PALETTE DIM *n***

Palettes being specified in the **LAYER PALETTE BANK** and **SPRITE PALETTE BANK** commands use *n* bits per colour (*n*=8 or 9), ie 256 bytes or 512 bytes (default value is *n*=9).

#### **PALETTE FORMAT *n***

Enable the ULANext extended palette with *n* INKs (1,3,7,15,31,63,127 or 255)

When the ULANext extended palette is enabled, BRIGHT and FLASH are not allowed (in standard and Timex hi-colour modes), and INK and PAPER accept the appropriate new range of values (layer 1 modes only - see later notes).

If *n*=0, disables the ULANext extended palette and uses standard attributes with 8 inks, 8 papers, bright and flash.

#### **PALETTE OVER *n***

Sets the global transparency colour to *n* (default value is 227)

#### **PALETTE CLEAR**

Resets all palettes and related settings to defaults. This is also done by **NEW**.

## **Sprites**

The *Next* provides 128 sprite objects and 64 sprite patterns (size 16x16 pixels). These can be manipulated with the following new commands:

### **SPRITE BANK *b***

Defines all 64 sprite patterns using the 16K of data (256 bytes per pattern) in bank *b*.

### **SPRITE BANK *b,offset,p,n***

Defines *n* sprite patterns starting with pattern *p*. Pattern data begins at offset *offset* in bank *b*.

### **SPRITE PALETTE *n***

Switch to using sprite palette *n* (0 or 1)

### **SPRITE PALETTE *n* BANK *b,offset***

Set sprite palette *n* from bank *b*, at offset *offset*. Either 256 bytes or 512 bytes of data is used, depending upon the **PALETTE DIM** setting.

### **SPRITE PALETTE *n,i,v***

Set sprite palette *n*, index *i* to value *v*

NOTE: *v* is always specified as a 9-bit value RRRGGGBBB (0-511) regardless of the **PALETTE DIM** setting, and can be conveniently specified using the standard Spectrum **BIN** function.

### **SPRITE PRINT *n***

Enable (*n*=1) or disable (*n*=0) sprites

### **SPRITE BORDER *n***

Enable (*n*=1) or disable (*n*=0) sprites over the border

### **SPRITE *s,x,y,p,f,rf,mx,my***

Set sprite *s* to position (*x,y*), pattern *p*, x-scaling *mx* and y-scaling *my*. If the sprite id *s* is negative, this sprite is a *relative* sprite, and its position is relative to the previous *anchor* sprite (defined with a positive sprite id). See later for more information on relative sprites.

The flags parameter, *f*, is a bitmask:

- bit 0: visible flag
- bit 1: rotate flag
- bit 2: Y-mirror flag
- bit 3: X-mirror flag
- bits 4..7: palette offset (or zero)

The relative-flags parameter, *rf*, is a bitmask:

- bit 0: type: 0=composite, 1=unified [only valid for anchor sprites]
- bit 1: pattern is relative to the anchor [only valid for relative sprites]
- bit 2: palette offset is relative to the anchor [only valid for relative sprites]

The scaling parameters *mx* and *my* are: 0=1x (no scaling), 1=2x, 2=4x, 3=8x.

Any parameter(s) in the **SPRITE** command can be omitted, and its value will be left unchanged from the last time it was explicitly specified.

(Again, the **BIN** function can be used to specify the flag parameters more conveniently.)

### **SPRITE DIM *x1,y1,x2,y2***

Sets the clip window for sprites from (*x1,y1*) to (*x2,y2*). Any part of a sprite outside this window is not visible. Note that this has no effect if sprites over the border (**SPRITE BORDER 1**) is enabled.

### **SPRITE CLEAR**

Resets the sprite attributes and global settings to defaults. This is also done by **NEW**.

### Relative sprites

Sprites can be grouped together to form "composite" or "unified" sprites. Each such grouping consists of a single "anchor" sprite (this is always the sprite with the lowest sprite id in the grouping) followed by any number of "relative" sprites, with sprite ids following the anchor sprite in sequence.

When an anchor sprite is moved or made invisible, all the associated relative sprites are also moved or made invisible. It is also possible for individual relative sprites to be made invisible or visible. The rule is that a relative sprite is only visible if its own visibility flag is set **and** the visibility flag of the associated anchor sprite is set.

To define a relative sprite, simply specify its sprite id as a negative number (eg specifying **SPRITE -1,...** defines sprite 1 as relative to the preceding anchor sprite, 0). Any number of relative sprites can follow an anchor sprite.

The x and y coordinates specified in **SPRITE** commands for relative sprites are not actual coordinates, but signed offsets in the range -127 to +127 from the coordinates of the anchor sprite.

Additionally, if the "pattern relative" flag is set for a particular relative sprite, its pattern number is added to the pattern number from the anchor sprite (wrapping round if the sum exceeds 64). Using this, it is easy to animate an entire composite/unified sprite simply by changing the pattern of the anchor sprite.

Similarly, if the "palette relative" flag is set for a particular relative sprite, its palette offset is added to the palette offset from the anchor sprite (wrapping round if the sum exceeds 16).

### Composite vs Unified sprites

The type of a grouping of sprites is determined by the "type" flag of the anchor sprite.

For composite sprites, the remaining sprite parameters (rotation, x/y mirrors and x/y scaling) are independent for each relative sprite. This allows creation of a composite sprite where individual relative sprites can be rotated etc for animation purposes.

For unified sprites, the rotation and x/y mirrors of the relative sprites are relative to that of the anchor sprite. Therefore, when the rotation or x/y mirrors of the anchor are changed, all the relative sprites rotate or reflect about the anchor.

Additionally, for unified sprites, the x/y scaling of the individual relative sprites is ignored, and the x/y scaling of the anchor sprite is applied to all sprites in the grouping, allowing the entire grouping to be scaled just by changing the scaling of the anchor.

### Batching

The standard **SPRITE** command normally has immediate effects to what is displayed on the screen. However, it is also possible to place **NextBASIC** into *batching* mode. In this mode, the standard **SPRITE** command has no immediate effect, but the changes specified are remembered. When all the required changes have been made (using multiple **SPRITE** commands) they can all be applied to the screen at once, giving a more synchronised look to your game. The following commands control this mode:

#### **SPRITE STOP**

Turns off immediate updates and enables batching mode.

#### **SPRITE RUN**

Turns immediate updates back on, disabling batching mode (this is also done by the **SPRITE CLEAR** command).

## **SPRITE MOVE**

When batching mode is enabled, sends all outstanding sprite changes to the hardware immediately.

## **SPRITE MOVE INT**

The same as **SPRITE MOVE**, but first waits for the 50/60Hz interrupt. This can be used to synchronise your game to the framerate.

## **SPRITE MOVE INT y**

The same as **SPRITE MOVE INT**, but changes are not sent to the hardware until after the TV scanline corresponding to sprite coordinate *y*. This can be used to avoid flicker by ensuring sprite changes don't occur whilst the TV is midway through displaying the sprite(s) in question.

## Automatic sprite movement

In order to reduce the amount of work a **NextBASIC** program needs to do to animate and move sprites, commands are provided to allow some or all of this work to be done automatically whenever a **SPRITE MOVE** command is issued. Any sprite can have automatic movement or animation applied to it, and the standard **SPRITE** command can still be used to perform any other changes when they are needed.

The main command for setting up automatic sprite movement is the **SPRITE CONTINUE** command:

```
SPRITE CONTINUE s, [x1 [TO x2]] [STEP xs] [RUN or STOP],  
                  [y1 [TO y2]] [STEP ys] [RUN or STOP],  
                  [p1 [TO p2]],  
                  [f], [r], [d]
```

As indicated by the square brackets, each parameter (or sub-clause of a parameter) is optional. If not specified, the previous value will be retained.

Movement in the x-direction is specified with:

- x1: minimum value for x-coordinate
- x2: maximum value for x-coordinate (=x1 if not provided)
- xs: signed step in pixels (-127..+127) for every move
- RUN**: indicates movement in the x-direction is initially **on**
- STOP**: indicates movement in the x-direction is initially **off**

Movement in the y-direction is specified with:

- y1: minimum value for y-coordinate
- y2: maximum value for y-coordinate (=y1 if not provided)
- ys: signed step in pixels (-127..+127) for every move
- RUN**: indicates movement in the y-direction is initially **on**
- STOP**: indicates movement in the y-direction is initially **off**

Pattern animation is specified with:

- p1: minimum value for sprite pattern
- p2: maximum value for sprite pattern (=p1 if not specified)

Movement rates are controlled with:

- r: rate at which sprite moves/animates (0-255)
  - 0=on every **SPRITE MOVE** command
  - 1=skip 1 **SPRITE MOVE** command after moving
  - 2=skip 2 **SPRITE MOVE** commands after moving
  - etc
- d: delay before initial movement (0-255)
  - 0=move on the first **SPRITE MOVE** command
  - 1=skip 1 **SPRITE MOVE** command before the first move
  - 2=skip 2 **SPRITE MOVE** commands before the first move
  - etc

The flags parameter, *f*, is an 8-bit mask (best specified with BIN):

- bits 1..0: behaviour when x,y limits are reached:
  - 00 = reflect this direction
  - 01 = stop this direction, start other direction
  - 10 = stop this direction
  - 11 = stop completely and make sprite invisible
- bit 2: flip the Y-mirror flag when y limits are reached
- bit 3: flip the X-mirror flag when x limits are reached
- bit 4: behaviour of pattern change:
  - 0 = cycle upwards, wrapping back to lower limit
  - 1 = bounce between lower and upper limits
- bit 5: if set, sprite is disabled when pattern reaches limits
- bit 6: if set, update pattern even when sprite is stationary
- bit 7: if set, X-mirror/Y-mirror/rotation flag are set according to direction of travel (overrides bits 2 & 3)

The initial position, pattern and other details of the sprite are determined by the last standard **SPRITE** command. If these values are outside the maximum/minimum ranges, then (depending upon the specified step and RUN/STOP status) they will gradually change until they fall within the max/min range.

If automatic movement is specified for an anchor sprite then, as you might expect, the entire composite/unified sprite will be automatically moved.

Automatic movement can also be specified for individual relative sprites if desired (the parameter *s* is always positive for the **SPRITE CONTINUE** command, but the sprite remains relative if specified as such in the last standard **SPRITE** command). Most typically this would be done to animate the relative sprites separately, so that one relative sprite might animate whilst the others remain the same (for example). However, it can also be used to automatically move a relative sprite around within a composite/group sprite. The main restriction here is that the movement limits are unsigned, so this works best for relative sprites with positive offsets (add 256 to negative offsets when specifying them in a movement range).

Automatic movement can be temporarily suspended for particular sprites if desired:

**SPRITE PAUSE** *s1* [**TO** *s2*]

Turns off automatic movement for a single sprite or range of sprites.

**SPRITE CONTINUE** *s1* [**TO** *s2*]

Turns automatic movement back on for a single sprite or range of sprites.

### Sprite functions

Several functions are provided to return details about sprites, and to make collision detection checks.

**NOTE:** All these functions are currently available only in the integer expression evaluator, so can only be present in an expression that starts with %.

**%SPRITE** *s*

Returns 1 (true) if sprite is visible, 0 (false) if not visible

**%SPRITE CONTINUE** *s*

Returns a bitmask describing the automatic movement enabled for this sprite:

- bit 0: set if automatic movement is enabled
- bit 1: set if currently moving in the Y direction
- bit 2: set if currently moving in the X direction

(If bit 0 is set but neither bit 1 or 2 is set, only the pattern is being animated).

#### **%SPRITE AT(s,c)**

Returns a coordinate or other movement-related value for the sprite:

<b>%SPRITE AT(s,0)</b>	returns x coordinate
<b>%SPRITE AT(s,1)</b>	returns y coordinate
<b>%SPRITE AT(s,2)</b>	returns pattern number
<b>%SPRITE AT(s,3)</b>	returns x step
<b>%SPRITE AT(s,4)</b>	returns y step
<b>%SPRITE AT(s,5)</b>	returns delay before the sprite next moves

(0 means the sprite will move on the next **SPRITE MOVE** command)

#### **%SPRITE OVER(s1, s2 [TO s3] [,overlapX [,overlapY] ])**

Performs bounding-box collision detection between sprite *s1*, and a single other sprite *s2* or a range of sprites *s2..s3*.

Optional acceptable overlaps (in pixels) can be provided in *overlapX* and *overlapY*. If *overlapX* is not present, 0 (no overlap) is used. If *overlapY* is not present, then the value of *overlapX* is used. Overlaps should be 0..7 for an unscaled sprite *s1*, or 0..15 for a 2x scaled sprite etc.

Returns 0 (false) if there is no collision

Returns the number of the colliding sprite (*s2..s3*) if there was a collision.

#### **NOTE:**

If the colliding sprite (*s2..s3*) is id 0, 128 is returned.

#### **NOTE:**

Any relative sprites following *s2* or *s3* will also be checked, until the next anchor sprite not in the specified range.

## Layers and modes

The *Next* provides various new graphics modes, to which *NextBASIC* gives access using the **LAYER** command.

There are conceptually 3 layers of graphics which can be seen on the screen at the same time (the 3 layers can be placed in any front-to-back order). The top layer is usually the sprites, which are manipulated with the **SPRITE** command. The other 2 layers are manipulated by the **LAYER** command. The "bottom" of these two layers can only be seen where the "top" layer has the transparency colour (227).

Layer 1 is the ULA screen, and by default is the bottom layer.

This can be in any of 4 different modes:

- mode 0: lo-res mode (128x96 pixels, each can be any of 256 colours)
- mode 1: standard Spectrum screen mode (256x192 pixels, with 32x24 attributes)
- mode 2: Timex hi-res mode (512x192 pixels, monochrome but with 8 different selectable global ink/paper combinations)
- mode 3: Timex hi-colour mode (256x192 pixels, with 32x192 attributes)

Layer 2 is 256x192 pixels, each can be any of 256 colours. By default it is the top layer but disabled, so does not usually obscure the layer 1 screen.

The **LAYER** command allows either layer to be selected (and for layer 1, any of the 4 available modes to be selected). After the **LAYER** command takes effect, all of the following standard Spectrum commands take place on the selected layer/mode (until another **LAYER** command is issued):

- INK, PAPER, BRIGHT, FLASH, OVER, INVERSE**
- CLS**
- PLOT, DRAW, CIRCLE**
- PRINT, LIST, CAT** etc (through the standard "s" channel, usually on stream 2)

NOTE: The **ATTR**, **POINT** and **SCREEN\$** functions do not take account of the layer/mode settings, and only refer to the standard Spectrum screen. However, instead, the following new command is available:

**POINT** *x,y* **TO** *var*

Checks the pixel on the current layer at (*x,y*) and stores the value in variable *var*.

The value will be 0 or 1 for standard Spectrum modes and Timex hi-res and hi-colour modes (pixel off or on). The value will be 0-255 for lo-res and layer 2 (actual pixel colour).

**BRIGHT** and **FLASH** are only effective in standard and hi-colour modes (and only when the ULANext extended palette is not enabled).

**INK** and **PAPER** values can range from 0..255 in lo-res and layer 2.

In hi-res mode, either **INK** or **PAPER** can be used to select the appropriate colour scheme (see list later).

The **LAYER** command also allows you to select layer 0. This is the default layer/mode when *NextZXOS* starts and is identical to the standard Spectrum screen mode used on 48K/128K Spectrums. This is the mode you should select in order to load and run standard Spectrum software.

You can switch back and forth between layer 1 and layer 2 without affecting what is on the screen (as long as you always select the same layer 1 mode each time). This allows BASIC programs to enable and manipulate both layer 1 and layer 2 screens, and use transparent areas so that both can be seen together.

The following **LAYER** commands are available:

### **LAYER 0**

Select layer 0, standard Spectrum mode

### **LAYER 1,0**

Select lo-res mode

**LAYER 1,1**

Select standard resolution mode

**LAYER 1,2**

Select Timex hi-res mode

**LAYER 1,3**

Select Timex hi-colour mode

**LAYER 2**

Select layer2

**LAYER 2,0**

Select layer2, and disable displaying it

**LAYER 2,1**

Select layer2, and enable displaying it

**LAYER PALETTE *n***

Switch to using palette *n* (0 or 1) for the current layer

**LAYER PALETTE *n* BANK *b*,*offset***

Set palette *n* for the current layer from bank *b*, at offset *offset*. Either 256 bytes or 512 bytes of data is used, depending upon the **PALETTE DIM** setting.

**LAYER PALETTE *n*,*i*,*v***

Set palette *n* for the current layer, index *i* to value *v*

NOTE: *v* is always specified as a 9-bit value RRRGGGBBB (0-511) regardless of the **PALETTE DIM** setting, and can be conveniently specified using the standard Spectrum **BIN** function.

**LAYER AT *x*,*y***

(Layer 2 or lo-res only).

Set the display offset for the top-left of the screen for the current layer to *x*,*y*. This is used for scrolling effects.

**LAYER OVER *n***

Set sprite/layer SLU ordering:

<i>n</i> = <b>BIN</b> 000	sprites over layer2 over ULA (layer1)	- the default
<i>n</i> = <b>BIN</b> 001	layer2 over sprites over ULA (layer1)	
<i>n</i> = <b>BIN</b> 010	sprites over ULA (layer1) over layer2	
<i>n</i> = <b>BIN</b> 011	layer2 over ULA (layer1) over sprites	
<i>n</i> = <b>BIN</b> 100	ULA (layer1) over sprites over layer2	
<i>n</i> = <b>BIN</b> 101	ULA (layer1) over layer2 over sprites	

**LAYER BANK *n*,*m***

(Layer 2 only). Set current banks *n*..*n*+2 as frontbuffer (to be displayed) and banks *m*..*m*+2 as backbuffer (for rendering). These values can be the same and both default to 9.

This command always applies to the layer 2 banks, but can be executed in any mode.

**LAYER ERASE *x*,*y*,*w*,*h*****LAYER ERASE *x*,*y*,*w*,*h*,*f***

(Layer 2 or lo-res only).

Fill region width *w* pixels, height *h* pixels, top-left corner *x*,*y* with value *f*. If *f* is not specified, the current global transparency value (usually 227) is used.

**LAYER DIM *x1*,*y1*,*x2*,*y2***

Sets the clip window for the current layer from (*x1*,*y1*) to (*x2*,*y2*). Areas of the layer outside this window are not visible. Note that all layer 1 modes and layer 0 share the same clip window; layer 2 has its own separate clip window.

**LAYER CLEAR**

Reset all layer information to defaults. This is also done by **NEW**. Resets banks, mode, layer2 enable, layer offsets, layer ordering. Also resets mode windows to default settings (such as character set size, auto-pause etc).

#### Differences between layer 0 and layer 1 mode 1.

Layer 0 behaves in exactly the same way as the screen always has on 48K and 128K Spectrums. Layer 1 mode 1 has the same resolution and attributes, but behaves in a slightly different manner under *NextBASIC*. It shares this same behaviour with all other layer 1 modes (and layer 2).

In layer 0, the standard Spectrum memory map is in force (ROM, RAM 5, RAM 2, RAM 0). However, in all layer 1 modes, the top 8K of RAM 5 is replaced with 8K from the *NextZXOS* RAM 8 bank. This is done so that BASIC still has access to the same amount of memory as usual (~41K); without this change, it would lose about 6K to the new screen modes.

The other main differences are:

Layer 0 pixel coordinates (used by **PLOT**, **DRAW**, **CIRCLE**) run from (0,0) at the bottom left on the main screen area to (255,175) at the top right. The bottom two screen lines are not normally accessible to these commands. However, in layer 1/2 modes, pixel coordinates run from (0,0) at the top left of the screen to (255,191) at the bottom right (511,191 in hi-res mode, 127,95 in lo-res mode). In layer 1/2 modes it is also allowed to draw points, lines and circles so that they go partly off-screen without generating "out of screen" errors.

Layer 0 **PRINT** coordinates (on channel "s") are in character squares, defined as (0,0) at the top left and (21,31) at the bottom right (again, the lower screen is not usually accessible).

Layer 0 only accepts standard colour ranges (0..7 for **INK/PAPER** etc). Colours from the extended ULANext palette with numbers higher than 7 can generally only be specified in layer 1 (mode 1 - standard, or mode 3 - Timex hi-colour). For layer 0 you can, however, POKE the system variable ATTR\_P with the calculated attribute value required and the desired ULANext colours will be used.

Layer 1/2 modes all use a full-screen system-defined text window for any **PRINTs** directed to channel "s". Therefore they generally use the same control codes as other text windows (except justify and save/load are not available).

In layer 1/2, therefore, **PRINT AT** y,x uses character coordinates (as on layer 0), but this will not always be 24 lines by 32 characters, depending upon whether different character size (and/or reduced height mode) has been selected. Note that double-width/double-height modes don't affect the coordinate system used.

In layer 1/2, it is also possible to use **PRINT POINT** x,y to change the print position. This uses the same pixel coordinate system used by **PLOT/DRAW/CIRCLE**.

By default, scrolling auto-pause is turned on for the layer 1/2 mode full-screen windows, so after a screen full of text has been printed the user must press SPACE to continue. This behaviour can be disabled using control code 26, as with other windows.

Layer 1/2 modes do not support "9" to mean contrast (for **PAPER/INK**) or "8" to mean transparent (for **PAPER/INK/BRIGHT/FLASH**). These are taken to mean actual colour numbers from the ULANext extended palette.

#### Timex Hi-Res colour scheme

The colour scheme for hi-res mode is selected using **INK** or **PAPER** (either as a direct command or by **PRINTing** to the hi-res screen or a window). This will immediately change the whole colour scheme. The colour schemes available (can be

altered using ULANext palettes) are:

INK 0 (or PAPER 7)	black on white
INK 1 (or PAPER 6)	blue on yellow
INK 2 (or PAPER 5)	red on cyan
INK 3 (or PAPER 4)	magenta on green
INK 4 (or PAPER 3)	green on magenta
INK 5 (or PAPER 2)	cyan on red
INK 6 (or PAPER 1)	yellow on blue
INK 7 (or PAPER 0)	white on black

### Tiling commands

For layer 2 and lo-res modes, there are new commands available to draw complete screens (or sections of a screen) from a set of tiles and a tilemap.

Tiles are either 8x8 pixels in size or 16x16 pixels in size. This allows a 16K bank to hold 256 8x8 tiles or 64 16x16 tiles. Tiles are numbered 0..255. Therefore, a complete set of 8x8 tiles occupies a single 16K bank, and a complete set of 16x16 tiles occupies 4 16K banks. If you use 16x16 tiles, you can restrict the tile numbers used and therefore reduce the memory requirements (eg if you need 64 or fewer different tiles, only 1 16K bank is required).

A tilemap is a linear map of 8-bit tile numbers. The user can specify any width up to 2048 tiles; each row of tiles follows directly after the previous one. The tilemap must be fully contained in a single 16K bank. This gives a maximum tilemap size of 256x64, 128x128, 2048x8 etc.

Any pixels in a tile which are the same colour as the current global transparency colour (which defaults to **227**) will not be written to the screen. If you want to draw pixels containing the global transparency colour you can temporarily change it to another colour (not used in your tiles) using the **PALETTE OVER** command before using **TILE**. Alternatively, you can use the **LAYER ERASE** command to clear regions of the screen to the global transparency colour before drawing tiles on top.

Information on layer 2 and lo-res tilemaps is stored separately, so you can use both. The **TILE** commands affect the currently selected layer/mode. They are:

#### **TILE BANK *n***

Define bank *n* as containing the tiles (up to 4 banks *n*..*n*+3 if 16x16 tiles)

#### **TILE DIM *n,offset,w,tilesize***

Define bank *n* as containing the tilemap, starting at offset *offset* in the bank. The tilemap is width *w* (1-2048) and uses 8x8 (*tilesize*=8) or 16x16 (*tilesize*=16) tiles.

#### **TILE**

##### **TILE AT *x,y***

Draw entire screen from tilemap, from tile offset *x,y* in the tilemap (0,0 if not specified).

##### **TILE *w,h***

##### **TILE *w,h* AT *x,y***

##### **TILE *w,h* TO *x2,y2***

##### **TILE *w,h* AT *x,y* TO *x2,y2***

Draw section of screen from tilemap.

Number of tiles to draw is width *w*, height *h*.

Draw from tile offset *x,y* in the tilemap (or 0,0 if not specified).

Draw to tile offset *x2,y2* on the screen (or 0,0 if not specified).

### Text window changes

There are some changes to the text window channels from those used in the +3e.

As noted earlier, there are 4 system-maintained full-screen windows which are used for all **PRINT**ing through the standard "s" channel when one of the layer 1 modes is selected, and most of the changes were made to accommodate this.

Windows can only be used in the same layer/mode that was active when they were defined. Control codes not listed here behave in exactly the same way as on +3e v1.43. The full list of original +3e window control codes is shown here:

<http://www.worldofspectrum.org/zxplus3e/channels.html>

<u>Control code</u>	<u>Differences</u>
0	On user-defined windows, turns justification off (as +3e) On system windows, increases the current character set width (can range from 3 to 8 pixels), and moves the cursor to the start of the next line.
1	On user-defined windows, turns justification on (as +3e) On system windows, decreases the current character set width (can range from 3 to 8 pixels), and moves the cursor to the start of the next line.
2	On user-defined windows, saves window contents (as +3e) On system windows, causes the size 8 character set to be replaced with the character set defined by the CHARS system variable.
3	On user-defined windows, restores window contents (as +3e) On system windows, causes the size 3..7 character sets to be regenerated
15	Wash window. This does nothing on layer 2 or lo-res windows.
18,n	FLASH n. Ignored unless in standard or Timex hi-colour modes, and ULANext is not enabled.
19,n	BRIGHT n. Ignored unless in standard or Timex hi-colour modes, and ULANext is not enabled.
22,y,x	AT y,x. Position is specified in terms of character positions (dependent upon the character size currently selected and whether reduced-height text is in operation. Double-width and double-height do not affect the coordinates, however).
23,nLow,nHigh	TAB n (same as +3e, but documentation incorrect on +3e site).
24,n	ATTR n. Ignored in lo-res, layer2 and Timex hi-res modes.
25,y,xLow,xHigh	POINT x,y. Changes print position to pixel coordinates x,y.  Previously this control code turned on or off extended UDGs for codes 165-255 instead of keyword tokens. Under <i>NextZXOS</i> extended UDGs are always used (LIST will expand keywords so keyword token codes will not normally be seen by windows anyway)
26,n	Auto-pause every n character lines. After each n character lines have been scrolled out of the window, output will automatically pause until the SPACE key is pressed (the bottom right character in the window will be flashed to indicate SPACE is being waited for). After a window has been cleared, the first pause occurs before any lines have been scrolled out; subsequent pauses wait for n character lines. Typically you would want to set "n" to the

height of the window.  
If set to zero (the default), auto-pause is disabled.

- 30,n            On user-defined windows, selects justification mode 0, 1 or 2 (as +3e).  
              On system windows, changes the current character set width to *n* (can be 3,4,5,6,7 or 8 pixels), and moves the cursor to the start of the next line.
- 31,n            On user-defined windows, selects whether embedded codes are permitted in justify mode (as +3e).  
              On system windows, causes the size *n* character set to be replaced with the character set defined by the CHARS system variable.

### User character sets

If the default character set(s) are replaced using control codes 2, 3 or 31 in a system window, any subsequent text printed in any window (which doesn't have its own user-defined character set) will use the new character set(s).

The system-defined character sets are partially shared: sizes 3 and 4 use the same set (only the leftmost 3 pixels are used for size 3), and similarly so do sizes 5 and 6. This should be borne in mind when replacing system character sets using control code 31.

### Window input

Text windows now support the **INPUT** command, as in *ResiDOS*. If you use **INPUT #**, then a cursor is added to the window at the current position. The user can then input any text desired, using the left and right arrows to move along the text input so far, or the up and down arrows to move to the start or end of the text. The DELETE key deletes the character to the left of the cursor, and the ENTER key completes the input. Up to 191 characters can be accepted into each input variable.

**INPUT #** may also now be used with other channels such as file, memory and variable channels. In these cases it is advisable to avoid any accidental outputs to the channels, by not using any prompt strings, and by using only the semicolon as a separator. In most cases you will want to input a string using the **LINE** modifier; without this, the data in the file (or other channel) would need to be surrounded with quotes.

### Window definitions

Windows are still defined using character squares as before. In lo-res mode, this means the maximum window size is 16x12 (not 32x24). In hi-res mode, "character squares" are considered to be 16 pixels wide, so the maximum window size is still 32x24 for this mode.

### Memory constraints

It should be noted that saving/loading window contents (only available on user-defined windows) is a costly operation. The amount of memory required for each character square is:

- 9 bytes (standard resolution mode)
- 16 bytes (Timex hi-res or hi-colour modes)
- 64 bytes (lo-res or layer2 modes)

For example, a 10x10 window in layer2 would require 6400 bytes of available memory for saving the contents.

### **BASIC Program Extensions**

It is now possible to write BASIC programs larger than the usual ~41K with a little extra effort. Sections of BASIC programs can be copied into any memory bank available to the user (and saved/loaded with the **SAVE/LOAD..BANK** commands), and the program can then switch between lines in the "main" program area and a bank.

The following new commands are available to manage banked sections of BASIC programs:

#### **BANK *n* LINE *x,y***

Copies lines *x* to *y* inclusive from the main program to bank *n*. The total number of bytes used in the bank will be shown.

Once this has been done it is not possible to change or delete any lines in the banked section (except by completely overwriting the bank's contents using another **BANK...LINE** command).

#### **BANK *n* LIST**

##### **BANK *n* LIST *l***

##### **BANK *n* LIST PROC *name()***

List lines (optionally from *l* or procedure named *name*) in bank *n*

#### **BANK *n* MERGE**

Copy all lines back from bank *n* into the main program

#### **BANK *n* GOTO *l***

GOTO line *l* in bank *n*. To GOTO the main program from a banked section, use *n*=255.

#### **BANK *n* GOSUB *l***

GOSUB line *l* in bank *n*. To GOSUB the main program from a banked section, use *n*=255.

#### **BANK *n* PROC *name(expressionlist)***

##### **BANK *n* PROC *name(expressionlist)* TO *paramlist***

Call a procedure in bank *n*. To call a procedure in the main program from a banked section, use *n*=255.

#### **BANK *n* RESTORE *l***

Set the DATA pointer to line *l* in bank *n*

### **Working with BASIC programs**

The following additional commands are provided:

#### **LIST PROC *name()***

Lists program starting with the procedure named *name*.

#### **LINE *start,step***

Renums the BASIC program with new starting line number *start* and incrementing numbers by *step*.

#### **LINE MERGE *first,last***

Merges lines from *first* to *last* into a single line (separated by colons).

#### **ERASE *first,last***

Erases a specified section of BASIC program (from *first* to *last* line, inclusive).

#### **ERASE**

Erases the entire BASIC program (but leaves variables intact), and finish with an "OK" report.

### **Notes**

Any **GOTO** or **GOSUB** within a banked section will go to a line in the same bank.

Any **RETURN** or **ENDPROC** will always return to the calling bank.

**DEF FN** statements must be in the main program; they will not be searched for in banked sections.

Lines in banks can have the same numbers as main program lines.

Renumbers won't affect or take into account lines in banked sections.

Commands that affect program lines can only be used as direct commands, and not be part of a program. These are:

**ERASE** *first, last*

**LINE** *start, step*

**LINE MERGE** *first, last*

**BANK** *n* **LINE** *x, y*

**BANK** *n* **MERGE**

The exception is the new command:

**ERASE**

which erases all lines in the BASIC program (but leaves the variables intact) and finishes with an "OK" report. This is a useful command to have as the last line of your C:/NEXTZX0S/AUTOEXEC.BAS file.

## Miscellaneous other features

**CONT** and **RAND** may be used as abbreviations for **CONTINUE** and **RANDOMIZE**.

**LET** is now optional and may be omitted. For example, you may write:

```
10 x=54:h$="abcde"
```

instead of:

```
10 LET x=54:LET h$="abcde"
```

**;** (semi-colon) may now be used as an alternative to **REM**.

This is intended for use with dot-commands which can process such lines whilst *NextBASIC* ignores them. eg an assembler might use as follows:

```
1000 .assemble
1010 ; LD BC,1234
1020 ; RET
```

The following additional commands are provided:

### **RUN AT** *speed*

Changes the speed of the ZX Spectrum Next.

Allowable values for *speed* are:

0	(3.5MHz)
1	(7MHz)
2	(14MHz)
3	(28MHz)

### **REG** *reg,value*

Sets a Next Register.

eg to perform a soft reset:

```
REG 2,%@00000001
```

### **SPECTRUM 48**

Switches into 48K BASIC mode whilst retaining the current BASIC program (although *NextBASIC* commands and features will no longer be available). This differs from the existing **SPECTRUM** command, which leaves the Next configured as a 128K Spectrum in 48K BASIC mode. Instead, the **SPECTRUM 48** command leaves the Next configured as a genuine 48K Spectrum, with 48K timings, the original 48K BASIC ROM and with the 128K paging hardware disabled.

### **SPECTRUM LOAD**

Reconfigures the Next as a 128K Spectrum and launches the *Tape Loader* menu option.

## **Sound support**

The **PLAY** command has been augmented to support the Next's turbosound features (3xAY chips).

9 strings are now allowed:

- strings 1,2,3 correspond to channels A,B,C of AY 1
- strings 4,5,6 correspond to channels A,B,C of AY 2
- strings 7,8,9 correspond to channels A,B,C of AY 3

The **W** (waveform) parameter affects only the AY chip for the string in which it appears, so each chip may have a different value at once.

If more than 3 strings are provided, the default volume is reduced to 13 in order to prevent clipping when many channels are playing at once. If 3 or fewer strings are provided, the default volume is 15 (as before).

3 new parameters are provided, which affect only the AY chip for the string in which they appear:

### **L**

Restrict audio output for this AY chip to the left speaker only

### **R**

Restrict audio output for this AY chip to the right speaker only

### **S**

Allow audio output for this AY chip to go to both left and right speakers again

If the Next is set up with ABC stereo (which is the default), normally channel A goes to the left speaker, B goes to left and right, and C goes to right.

Therefore if the **L** parameter is used, only channels A and B from the current AY chip will be audible. Similarly, if **R** is used, only channels B and C will be audible.

## **BASIC program flow structures**

The **IF** command now supports **ELSE**, which precedes a list of commands to be executed if the test was false. The **ELSE** must be on the same line as the **IF**, and preceded by a colon.

**IF...THEN...ELSE** statements may be nested. For example:

```
10 IF x=0 THEN PRINT "null":BEEP 1,0:ELSE IF x=1 THEN PRINT "one":BEEP 1,1:ELSE
PRINT "x was ";x
```

Note that this is not "true" nesting since there is no marker to indicate the end of an **IF**. When any **IF** condition fails, execution skips to the code following the next **ELSE** statement within the same line.

A new looping structure is also available. The start of the loop is marked with **REPEAT** and the end with **REPEAT UNTIL condition**. This will keep repeating the loop until *condition* is true (use **REPEAT...REPEAT UNTIL 0** for an infinite loop).

Optionally, any number of **WHILE** statements may be present within the loop, taking the form: **WHILE condition**. If the condition is false the loop is terminated immediately and execution continues after the matching **REPEAT UNTIL** statement.

These features allow you to construct loops with conditions at the top or the bottom of the loop, or at points in between (or any combination of these).

**REPEAT** loops may be nested to any depth.

Examples:

```
10 LET address=32768
20 REPEAT
30   READ b
40 WHILE b>=0
50   POKE address,b
60   LET address=address+1
70 REPEAT UNTIL 0
80 DATA 62,25,1,112,17,201,-1
```

```
10 REPEAT
20   INPUT "Enter a number (-1 to end): ";n
30   PRINT n
40 REPEAT UNTIL n=-1
```

```
10 LET y=0
20 REPEAT : WHILE y<22
30   PRINT AT y,0;"This is line ";y
40 REPEAT UNTIL 0
```

```
10 REPEAT
20   INPUT "Stock item: ";x$
30 WHILE x$<>" "
40   INPUT "Quantity: ";n
50   PRINT x$;" : ";n
60 REPEAT UNTIL x$="END"
```

## Procedures and local variables

Named procedures can now be defined, using the following command:

**DEFPROC** *procedurename(paramlist)*

where *procedurename* follows the same rules as standard numeric variables (must start with a letter, and contain only letters, numbers and spaces; when matching names, the case of letters is unimportant and spaces are ignored)

and *paramlist* is an optional list of up to 8 variable names (simple strings, numeric variables or integer variables, but not arrays of any type). These names can be used within the procedure to reference the values that are passed in by the **PROC** command.

The execution of a procedure is terminated by the following command:

**ENDPROC**

It is possible to have more than one **ENDPROC** in a procedure (for example an early exit can be made with a command such as **IF condition THEN ENDPROC**).

A procedure is called with the following command:

**PROC** *procedurename(expressionlist)*

The number of expressions and each of their types must match those defined in the **DEFPROC**, otherwise a *Q Parameter Error* report will be generated. (Note that you can provide an integer expression for a numeric parameter or vice versa, but strings/numbers must be correctly matched).

Optionally, a procedure can return up to 8 results to the caller, with the following command variants:

**ENDPROC** = *expressionlist*

**PROC** *procedurename(expressionlist) TO paramlist*

Again, the types of expressions in the **ENDPROC** must match the types of the variables in the **PROC**'s *paramlist*. It is acceptable for the **ENDPROC** to provide more results than the **PROC** requires (or even for the **PROC** not to have a *paramlist* at all): the unneeded values will just be discarded.

Within a procedure (or within a subroutine called by **GOSUB**) it is possible to create local variables, which can be used within the procedure/subroutine without affecting any existing variables with the same name (the original values will be restored at the **ENDPROC** or **RETURN** command):

**LOCAL** *variablelist*

As with the *paramlist* in a **DEFPROC** (which is itself a set of local variable names for the procedure, initialised with the values from the **PROC** command), only simple string, numeric and integer variables can be made local; not arrays.

Each **LOCAL** statement can contain up to 256 variable names, and multiple **LOCAL** statements may be present in a subroutine or procedure; the only limit on the number of local variables that can be created is available memory.

Local variables are initialised to zero (or the empty string) by the **LOCAL** command.

Procedures may also be recursive. Here is a simple example:

```

10 INPUT "Enter a number 0+: ";x
20 PROC factorial(x) TO f
30 PRINT "The factorial of ";x;" is ";f
40 GOTO 10
999 STOP
1000 DEFPROC factorial(n)
1010 IF n<0 OR n<>INT n THEN PRINT "Factorial only possible for non-negative
integers":STOP
1020 IF n<=1 THEN ENDPROC=1
1030 LOCAL partial
1040 PROC factorial(n-1) TO partial
1050 ENDPROC=n*partial

```

## **Error-trapping**

Any error (except "0 OK" which is not considered an error) can be trapped by the **ON ERROR** command, allowing BASIC to recover from expected error conditions.

To turn on error trapping, use the command:

**ON ERROR** *statementlist*

This will cause the statements after the **ON ERROR** command to be executed whenever an error report would normally have been displayed. Note that this command *must* be part of a program and cannot be entered as a direct command.

To turn off error-trapping again, just use:

**ON ERROR**

This is required if you wish to generate errors again. eg the following will display "There was an error!" and terminate with the 9 *STOP statement* error when line 20 is executed:

```
10 ON ERROR PRINT "There was an error!":ON ERROR:STOP
20 PRINT 5/0
```

To generate the last error that actually occurred (this does not need error trapping to be turned off), use the command:

**ERROR**

eg this will print the message but still give the correct *Number too big* report.

```
10 ON ERROR PRINT "There was an error!":ERROR
20 PRINT 5/0
```

You can also obtain details of the last error using the following command:

**ERROR TO** *codevar,linevar,statementvar,bankvar*

This will store the error code in the numeric variable *codevar*, the line number in *linevar*, the statement number in *statementvar* and the bank number in *bankvar*. Note that you do not need to supply later variable names if you do not need the information, eg all of these are valid:

```
ERROR TO e
ERROR TO e,l
ERROR TO e,l,s
ERROR TO e,l,s,b
```

NOTE: Any errors generated by a dot command are indicated with an error code of 255 ("Dot Command Error").

## **Localised error-trapping**

As well as (or instead of) having a global error-trapping routine for your program, each procedure, subroutine and repeat loop may have its own local error-trapping routine, simply by using the **ON ERROR** command within it.

When an error occurs within a repeat loop, subroutine or procedure, it will be trapped by its own **ON ERROR** routine if there is one. If not, the error will be passed out to the next level and trapped by any **ON ERROR** routine there and so on. Only if there is no **ON ERROR** at any level above the command that caused the error will a normal error report be generated.

For example:

```

10 ON ERROR PRINT "Outer error handler!":ERROR
20 REPEAT
30   PRINT "Starting..."
40   ON ERROR PRINT "Oops!":ON ERROR:STOP
50   GO SUB 100
60   PRINT "Iterating..."
70   ON ERROR
80 REPEAT UNTIL 0
90 STOP
100 ON ERROR PRINT "Bad pigs!":RETURN
110 PROC myproc()
120 PRINT "Pigs: ";pigs
130 RETURN
200 DEFPROC myproc()
210   LOCAL m
220   ON ERROR PRINT "Myproc died...":ENDPROC
230   PRINT "m=";m,"n=";n
240 ENDPROC

```

Note that in **REPEAT** loops it is important to turn off any local error handling for that loop before the **REPEAT UNTIL** is executed. If not, the loop start cannot be found and a *Loop error* would result (and be trapped by the loop's own error handler). Removing line 70 in the example above would demonstrate this.

Also note that any **LOCAL** commands in a procedure or subroutine must come before a local error handler (ie lines 210 and 220 in the example cannot be reversed).

## Integer variables and expressions

For additional speed and memory efficiency, NextBASIC provides a new integer expression evaluator. Usually all integer values are treated as unsigned 16-bit values (signed 16-bit calculations and comparisons can also be performed, see later), and all operations are performed modulo 65535, with no checks for overflow/underflow (except division by zero, which results in error 6, Number too big).

An integer expression can be used in any BASIC line where a numeric expression is normally expected. To indicate an integer expression instead of a floating point expression, a % symbol must always precede an integer expression. It is important to note that after the % symbol has been used, all variable names in the expression refer to the specially-provided integer variables and arrays, and not the standard floating-point numeric variables.

Similarly, integer variables can be used in assignments (such as **LET**, **INPUT**, **READ**, **FOR**) by preceding their name with a %.

It is *not* generally possible to access standard numeric variables or functions within an integer expression (but see the special **INT{ }** notation later), or to access integer variables or operations within a standard numeric expression.

It is possible to assign an integer expression to a standard normal numeric variable, or vice-versa, and the value will be converted appropriately. For example, all the following assignments are valid:

**LET %A=2\*PI\*radius**

assigns truncated floating point calculation to integer variable A

**LET %B=%B+(A(7)<<3)**

shifts integer array element A(7) left 3 bits and adds to integer variable B

**LET addr=%x(1)<<8+x(0)**

calculates standard numeric variable *addr* from low and high bytes in integer array X elements 0 and 1

Note that **DEF FN** does not support user-defined integer functions.

**FOR..NEXT** loops may be used with integer variables as the index, eg:

```
10 FOR %i=%$c9 TO 220
20 PRINT %i
30 NEXT %i
```

Integer loops run much faster than loops using a standard floating point index variable, especially when loops are used towards the end of long programs. Integer **FOR..NEXT** loops run at the same speed regardless of where they are located in the BASIC program, but standard **FOR..NEXT** loops become progressively slower the later they are located in the program.

**STEP** values up to 32767 are allowed, as well as negative **STEP** values from -1 to -32767.

Note that although the loop index in an integer loop is treated as an unsigned value, this will actually work for signed loop limits as well (eg **FOR %i=-3 TO -7 STEP -1**). The one restriction is that both loop limits must be either positive or negative (eg **FOR %i=-3 TO 3 STEP 1** will not work).

## Integer variables

A fixed set of integer variables are provided: the user cannot define additional variables. The two main advantages of a fixed set of variables are:

- speed of access (all integer variables are at a known location)
- memory usage - the integer variables are stored in additional RAM reserved by NextZXOS, and hence do not use any space in the normal BASIC/variables area

All integer variables are erased to zero at **RUN**, **CLEAR** and **NEW**. Note, however, that integer variables are not saved/loaded along with BASIC programs, as is the case with normal floating-point and string variables. Therefore they survive a **LOAD** and can potentially be used to communicate information between BASIC programs.

There are 26 integer variables provided, named **A** to **Z** (can also be referred to in lower-case, **a** to **z**).

#### Integer arrays

There are also 26 integer variable arrays provided, named **A()** to **Z()** (or **a()** to **z()**), each containing 64 elements, numbered 0 to 63.

Note that array elements are numbered from 0, not 1 as in normal floating-point/string arrays. Also note that integer array element **A(0)** is *not* the same as integer variable **A**.

It is not possible to re-dimension integer arrays: for speed, these are pre-allocated. However, to provide a little more flexibility it is possible to treat the array memory in different ways using **[]** subscript notation instead of the normal **()** notation.

When using a single **[]** subscript, you can treat an integer array as having more than 64 elements. Additional elements are taken from subsequent arrays in memory. Accessing **C[n]** would use memory in arrays C,D,E.. in turn, depending upon the maximum value of *n* used. For example, if you required 200 elements so *n* ranged from 0..199, then 4 arrays C(), D(), E() and F() would be in use (200/64=3.13).

When using a double **[][]** subscript, you can treat a range of integer arrays as a single two-dimensional array. In this case, the first subscript indicates the integer array to be used (0=the named array, 1=the next array etc) and the second subscript is the element number (0..63). For example, accessing **G[n][m]** where *n* ranges from 0 to 7 would use the 8 arrays G()..N().

#### Available operators and functions

The following unary operators may precede any integer value or sub-expression:

<b>!</b>	bitwise not
<b>NOT</b>	logical not (gives 1 if argument is zero; otherwise gives 0)
<b>-</b>	two's complement (negate)

Literal numbers can be specified in decimal (the default), hexadecimal (preceded by the **\$** symbol) or binary (preceded by the **@** symbol), eg:

**32767**  
**\$ed01**  
**@11100010**  
**\$FF**

The following binary operators are available:

<b>+</b>	add
<b>-</b>	subtract
<b>*</b>	multiply
<b>/</b>	divide
<b>MOD</b>	modulus (remainder)
<b>&lt;&lt;</b>	shift left
<b>&gt;&gt;</b>	shift right
<b>&amp;</b>	bitwise AND
<b> </b>	bitwise OR
<b>^</b>	bitwise XOR
<b>&lt;</b>	less than
<b>&gt;</b>	greater than
<b>=</b>	equal to
<b>&lt;=</b>	less than or equal to

**>=** greater than or equal to  
**<>** not equal to  
**AND** logical and (if 1<sup>st</sup> arg is 0, gives 0; otherwise gives 2<sup>nd</sup> arg)  
**OR** logical or (if 2<sup>nd</sup> arg is 0, gives 1<sup>st</sup> arg; otherwise gives 1)

The six relational operators always produce a result of 0 for false and 1 for true.

The following integer functions are available (parentheses are optional):

<b>IN</b> <i>port</i>	read value from hardware port
<b>REG</b> <i>reg</i>	read value from Next register
<b>PEEK</b> <i>addr</i>	read byte from memory
<b>DPEEK</b> <i>addr</i>	read double-byte (16-bit word) from memory
<b>USR</b> <i>addr</i>	execute m/c routine and return value left in BC
<b>BANK</b> <i>n</i> <b>PEEK</b> <i>o</i>	read byte from offset in bank
<b>BANK</b> <i>n</i> <b>DPEEK</b> <i>o</i>	read double-byte (16-bit word) from offset in bank
<b>BANK</b> <i>n</i> <b>USR</b> <i>addr</i>	execute m/c routine in bank and return value left in BC
<b>RND</b> <i>n</i>	return random number in the range 0.. <i>n</i> -1
<b>BIN</b> <i>n</i>	synonym for @ <i>n</i> , specifying a binary value
<b>SPRITE</b> <i>s</i>	return 1 (true) if sprite is visible, 0 otherwise
<b>SPRITE CONTINUE</b> <i>s</i>	returns sprite movement status (see sprites section)
<b>SPRITE AT</b> ( <i>s,c</i> )	returns sprite coord/movement data (see sprites section)
<b>SPRITE OVER</b> ( <i>..</i> )	returns collision detection result (see sprites section)

Operations are performed in strictly left-to-right order, unless overridden by the use of parentheses.

#### Signed integer expressions

As noted earlier, by default all operators and functions in integer expressions treat their arguments as unsigned, and produce unsigned results. However, it is also possible to override this behaviour and evaluate signed 16-bit integer expressions, with values in the range -32768..32767. This is done by enclosing the part of the expression which should be evaluated as signed with the special **SGN{ }** notation. An integer sub-expression or (more usually) the entire integer expression can be treated in this way. eg:

```
LET x1=%SGN{-100/3}
LET x2=%50+SGN{-100/3}
```

The only operators that treat their arguments as signed within a signed integer expression are the arithmetic operators (**\*** **/** **MOD** **+** **-**) and the relational operators (**<** **<=** **=** **>=** **>** **<>**). All other operators and functions still treat their arguments as unsigned values.

#### Embedded floating-point subexpressions

It is also possible to use the special **INT{ }** notation to embed an expression that returns a standard numeric value within an integer expression. This, for example, allows calculations to be included that are not supported in the integer expression evaluator, or access to standard floating-point variables. eg:

```
LET %x=%x+INT{LEN x$}
LET %x=%x*INT{apples}
LET %x=%SGN{x+INT{(INKEY$="P" OR INKEY$="p")-(INKEY$="O" OR INKEY$="o")}}
```

## Installable device drivers

NextZXOS allows for a number of device drivers to be installed/uninstalled at will using the .install/.uninstall dot commands (currently a maximum of 4 drivers may be installed at any one time but this could change in the future).

These are mainly intended for use as drivers for external peripherals such as printers, mice, network devices etc, but could be used for other purposes.

To install or uninstall a driver, use the following dot commands:

```
.install drivename.drv
.uninstall drivename.drv
```

The documentation that comes with the driver describes how to use it. Some drivers may make use of the new **DRIVER** command. This has the following form:

```
DRIVER driverid,callid[,n1[,n2]] [TO var1[,var2[,var3]]]
```

where *n1* and *n2* are optional values to pass to the driver, and *var1*, *var2* and *var3* are optional variables to receive results from the driver call. The documentation for each driver will describe the individual **DRIVER** commands that you can use.

## Channel support

Some drivers can support input/output via the streams and channels system of the Spectrum Next. If so, the documentation will describe how to open a channel, using one of the following command variants (assuming the driver id is ASCII 'X'):

```
OPEN #n,"D>X"
```

open stream n to simple channel for device 'X'

```
OPEN #n,"D>X>string"
```

open stream n to channel described by *string* on device 'X'

```
OPEN #n,"D>X,p1"
```

open stream n to channel described by numeric value *p1* on device 'X'

```
OPEN #n,"D>X,p1,p2"
```

open stream n to channel described by numeric values *p1* and *p2* on device 'X'

```
CLOSE #n
```

close stream n

Once a channel is open, you can use any of *NextBASIC*'s stream input, output or pointer manipulation commands (some drivers may not support all of these; the documentation should describe what can be used). eg:

```
PRINT #n;....
```

```
INPUT #n;....
```

```
INKEY$ #n
```

```
RETURN #n,var      (get current stream pointer to variable var)
```

```
DIM #n,var         (get current stream size/extent to variable var)
```

```
GOTO #n,value      (set current stream pointer)
```

```
NEXT #n,var        (wait for next input character from stream and store in var)
```

### System variable changes

The following system variables have been changed (same format as +3 manual):

1	5B5FH (23391)	INKL	INK colour for lo-res mode (was BAUD)
1	5B60H (23392)	INK2	INK colour for layer2 mode (was BAUD+1)
1	5B61H (23393)	ATTRULA	Attributes for standard mode (was SERFL)
1	5B62H (23394)	ATTRHR	Attributes for hi-res mode (only paper colour in bits 3..5 is used) (was SERFL+1)
1	5B63H (23395)	ATTRHC	Attributes for hi-colour mode (was COL)
1	5B64H (23396)	INKMASK	Softcopy of ULANext inkmask(or 0)(was WIDTH)
N1	5B65H (23397)	LSBANK	Temp bank in LOAD/SAVE & others (was TVPARS)
X1	5B68H (23400)	FLAGN	Flags for the NextZXOS system (was XLOC)
1	5B69H (23401)	MAXBNK	Maximum available RAM bank (was YLOC)
1	5B73H (23411)	TILEBNKL	Tiles bank for lo-res (was RC LINE)
1	5B74H (23412)	TILEML	Tilemap bank for lo-res (was RC LINE+1)
1	5B75H (23413)	TILEBNK2	Tiles bank for layer2 (was RC START)
1	5B76H (23414)	TILEM2	Tilemap bank for layer2 (was RC START+1)
X1	5B77H (23415)	NXTBNK	Bank containing NXTLIN (was RC STEP)
X1	5B78H (23416)	DATABNK	Bank containing DATADD (was RC STEP+1)
N1	5B7BH (23419)	L2SOFT	Softcopy of layer2 port (was DUMPLF)
X1	5C7FH (23679)	GMODE	Graphical layer/mode flags (was P POSN)
1	5C81H (23681)	STIMEOUT	Screensaver control (was unused)
2	5CB0H (23728)		unused (was NMIADD)

The following system variables have been inserted where STRIP1 and STRIP2 were, within the temporary TSTACK area. This means that there are now a guaranteed 117 bytes of TSTACK when calling +3DOS:

2	5B7CH (23420)	TILEWL	Width of lo-res tilemap
2	5B7EH (23422)	TILEW2	Width of layer2 tilemap
2	5B80H (23424)	TILEOFFL	Offset in bank for lo-res tilemap
2	5B82H (23426)	TILEOFF2	Offset in bank for layer2 tilemap
2	5B84H (23428)	COORDSX	x coord of last point plotted (layer 1/2)
2	5B86H (23430)	COORDSY	y coord of last point plotted (layer 1/2)
1	5B88H (23432)	PAPERL	PAPER colour for lo-res mode
1	5B89H (23433)	PAPER2	PAPER colour for layer2 mode
Nx	5B8AH (23434)	TMPVARS	Base of temporary system variables (space shared with bottom of TSTACK)

## List of updates

### Updates: 30 March 2020

Clarified how integer loops work with negative loop limits and/or steps.

Noted that **CONT** and **RAND** can now be used as abbreviations for **CONTINUE** and **RANDOMIZE**.

Noted that **LET** is now optional (from v2.06A) and may be omitted.

### Updates: 25 March 2020

Documented the new sprite-related features added in v2.06:

- \* there are now 128 sprite objects
- \* the main **SPRITE** command is extended with 3 new parameters (*rf, mx, my*)
- \* all parameters in the main **SPRITE** command are now optional
- \* added new **SPRITE STOP**, **SPRITE RUN**, **SPRITE MOVE**, **SPRITE PAUSE** and **SPRITE CONTINUE** commands
- \* added new **SPRITE**, **SPRITE AT**, **SPRITE CONTINUE** and **SPRITE OVER** functions into the integer expression evaluator

### Updates: 30 January 2020

Added new **SPECTRUM 48** and **SPECTRUM LOAD** commands.

Updated NextZXOS version number referred to, for day zero release (v2.04).

### Updates: 29 November 2019

Added a couple of missing changes to the system variables.

### Updates: 28 November 2019

Added 23 (TAB) to list of window control code changes from +3e (not really a change, but mis-documented on the +3e site).

Added new commands (plus enhanced **POKE** and **BANK..POKE** commands):

**REG** reg,value

**POKE** addr,valuelist...

**BANK n POKE** addr,valuelist...

**DPOKE** addr,valuelist...

**BANK n DPOKE** addr,valuelist...

Added special-case assignment commands for reading strings from memory:

**LET stringdest = PEEK\$(addr, len)**

**LET stringdest = PEEK\$(addr, ~)**

**LET stringdest = PEEK\$(addr, ~char)**

**LET stringdest = BANK n PEEK\$(addr, len)**

**LET stringdest = BANK n PEEK\$(addr, ~)**

**LET stringdest = BANK n PEEK\$(addr, ~char)**

Revamped integer expressions section to include all the new features as at v2.03b, including:

alternative views of integer arrays using [] subscripting

**SGN{}** and **INT{}** sub-expressions

**IN**, **REG**, **PEEK**, **DPEEK**, **USR**, **BIN**, **RND**, **BANK..PEEK**, **BANK..DPEEK**, **BANK..USR** functions

**NOT**, - unary operators

**AND**, **OR** binary operators

Noted that **RUN AT** can now also select 28MHz.

Added new keyword token codes.

Clarified that **ENDPROC** always returns to the calling bank.

Removed deprecated **BANK..PEEK** and **BANK...USR** commands.

#### Updates: 23 October 2019

Added missing description of **BANK n PROC** command.

Fixed "main program" id from -1 to 255 in **BANK n GOTO/GOSUB/PROC** commands.

#### Updates: 18 May 2019

Clarified that integer variables survive across a **LOAD** command.

Fixed typo in one of the **REPEAT** examples.

#### Updates: 18 Oct 2018

Clarified that error trapping does work for dot commands.

#### Updates: 23 Aug 2018

Added new **BANK n USR address** command to execute machine-code routines in any bank.

#### Updates: 15 Aug 2018

Noted that **;** may be used as an alternative to **REM** (intended for dot command use, eg for an assembler).

#### Updates: 8 Jul 2018

Updated the list of new error messages.

#### Updates: 20 May 2018

Noted that **LAYER CLEAR** also resets mode windows to default settings.

Added **LIST PROC**, **BANK..LIST PROC**, **RUN AT** and **LINE MERGE** commands.

Updated text windows: control code 25 is now used to specify a new print position using pixel coordinates.

Updated notes on layers to reflect that **PRINT AT** now uses character position coordinates (as with layer 0) and that there is a new **PRINT POINT** facility which allows position to be specified with pixel coordinates.

#### Updates: 19 Feb 2018

Noted that **PLOT/DRAW/CIRCLE** in layer 1/2 modes may be drawn so that they are partly off-screen without generating "out-of-screen" errors.

Updated system variables (**COORDSX**, **COORDSY**, **PAPERL**, **PAPER2** replacing some previously-described variables).

Added section describing enhancements to the **PLAY** command.

#### Updates: 12 Feb 2018

Added new procedures support (**DEFPROC**, **ENDPROC**, **PROC**, **LOCAL** commands).  
Added new error-trapping support (**ON ERROR**, **ERROR**, **ERROR TO** commands).  
Updated keywords list.  
Updated error message list.  
Changed **POINT x,y,var** command syntax to **POINT x,y TO var**.  
Changed **BANK n PEEK offset,var** command syntax to **BANK n PEEK offset TO var**.

#### Updates: 6 Feb 2018

Replaced modulus operator % with **MOD** (new token code \$8d).  
Removed unary + and - operators from the integer expression evaluator.

#### Updates: 28 Jan 2018

Added new section on installable device drivers, with new **DRIVER** command.  
Moved the new system variables **INKL**, **INK2**, **ATTRULA**, **ATTRHR**, **ATTRHC**, **INKMASK** to newly-freed system variables (previously used for printer).

#### Updates: 17 Jan 2018

Copied descriptions of commands in earlier updates into the main text.  
Clarified that layer 2 banks cannot be released by the **BANK CLEAR** command.  
Added further notes and examples for the new structured programming commands.  
Added token codes for **REPEAT**, **WHILE** and **UNTIL**.

#### Updates: 15 Jan 2018

Clarified that all commands accessing banks mark them as "owned" by BASIC (except **BANK CLEAR** which releases them).  
Clarified that **LAYER BANK** may be executed in any mode, but always applies to layer 2.  
Added new **ERASE** command which erases all lines of a BASIC program. It may be used within a program, so is suitable as the last line of a C:/NEXTZXOS/AUTOEXEC.BAS file.  
Updated description of **LINE** command, which now just allows the whole program to be renumbered (but with any starting number and step).  
Added new **REPEAT...[WHILE]...REPEAT UNTIL** looping structure (see main text for full description).

#### Updates: 23 Dec 2017

Added new "Loop error" error and reworded "Direct command only" to "Direct command error".  
Clarified behaviour of integer **FOR/NEXT** loops.  
Added new **ELSE** command and token.

#### Updates: 12 Dec 2017

A new command (now in main text of the editor changes document) has been added:  
**SPECTRUM SCREEN\$ n,t**

Updated system variables with new **STIMEOUT** system variable.

#### Updates: 30 Nov 2017

The **BANK** command can now use banks 5,2,0 (the standard 48K memory) without restriction.

Added new **BANK...LAYER** command.

Noted that transparent pixels are not drawn by the **TILE** command.

#### Updates: 23 Nov 2017

Updated the notes on **INPUT #** which can now be used with other channels (file, memory, variable) as well as windows and the standard "K" channel.

The **REMOUNT** command should be entered when the user wishes to change the SD card. When the prompt "Remove/insert SD and press Y" is shown the SD card may be changed, and then the **Y** key should be pressed.

#### Updates: 14 Nov 2017

The auto-pause window control code (26,n) is changed: "n" is the number of character lines to be scrolled between pauses, not pixel lines. Also the bottom right-hand character square is now flashed rather than inverted to indicate when the window is paused and waiting for SPACE to be pressed.

By default, scrolling auto-pause is turned on for the layer 1/2 mode full-screen windows, so after a screen full of text has been printed the user must press SPACE to continue. This behaviour can be disabled using control code 26, as with other windows.

#### Updates: 6 Nov 2017

Removed "bright magenta" from description of the transparency colour (227) since the default value for ULA's bright magenta has been changed to 231 and so it no longer acts as a transparency.

Note that the same clip window (as specified by the **LAYER DIM** command) is shared between layer 0 and all layer 1 modes. Layer 2 has its own clip window (as do the sprites, this being specified by the **SPRITE DIM** command).

Added new command **REMOUNT** (token code \$99, with tokens << and >> now moved to \$97 and \$98 respectively). The **REMOUNT** command (no parameters) re-initialises the filesystem following an SD card change.

The following new command (now in the main text) will be added:

**BANK NEW var**

Behaviour of **NEW** in relation to banks has now changed: a **NEW** now does not mark banks reserved by BASIC as free again; this only happens at a reset.

#### Updates: 21 Oct 2017

STRIP1/STRIP2 removed from system variables and replaced with TMPVARS.  
INKHR system variable replaced with ATTRHR.

Clarified that the extended ULANext colour ranges are only allowed to be specified with **INK/PAPER** in layer 1 modes (mode 1 - standard, or mode 3 - Timex hi-colour). In layer 0 only the standard colour ranges 0..7 can be specified for **INK/PAPER** (although any desired ULANext colour scheme can be selected for use in

layer 0 by POKEing the calculated attribute value into the system variable ATTR\_P).

Clarified that hi-res colour schemes can be chosen using either **INK** or **PAPER**.

Clarified that **FLASH**, **BRIGHT** and **ATTR** commands and window control codes are ignored unless used in standard or Timex hi-colour modes (with **FLASH** and **BRIGHT** always ignored if ULANext colours are enabled).

#### **Updates: 10 Oct 2017**

There will no longer be a restriction on the address for user-defined character sets.

Clarified that changing character set size also causes the window print position to be moved to the start of the next line.

Clarified that window save/load is costly in terms of memory.

Clarified that all commands using the standard "s" channel (not just **PRINT**) will operate in the currently-selected layer/mode.

Window control code 26 is now "auto-pause" instead of "fill with byte".

Added new integer expressions section.

Added new token codes for >> and <<.

The following new command (now in the main text) will be added:

**BANK n CLEAR**

#### **Updates: 5 Oct 2017**

Updated text to clarify some details of how different attributes are handled in different modes.

The following new commands (now in the main text) will be added:

**LAYER DIM** x1,y1,x2,y2

**SPRITE DIM** x1,y1,x2,y2

**POINT** x,y,var